

取扱説明書: Ver 4.00

UG-023BR ファイヤーサイドグローブ ブラウン

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、焚火作業、ダッチオーブン等の調理用に設計された耐熱グローブです。 安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない 点及び製品に不具合が確認された際には直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

⚠ 警告:本製品には、カリフォルニア州で癌、先天性欠損症、その他生殖に関わる害を引き起こす可能性があることが知られている化学物質が含まれています。 より詳しい情報については下記WEBサイトをご参照ください。www.P65Warnings.ca.gov

各部の名称



スペック

- ●材質:アウターグローブ/牛革、インナーグローブ/難燃コットン、ポリエステル
- ●サイズ:フリーサイズ(全長340mm)
- ●重量:470g

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

↑ 警告 取扱いを誤った場合、使用者が死亡または重症を負う可能性があることを示します。

- ●ご使用の前に、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、 または弊社ユーザーサービス係に点検または修理を依頼してください。
- ●本製品には耐火性能はありません。直接炎に触れたり燃焼中の薪や炭に触れたりしないでください。
- ●高温のものに長時間触れないでください。徐々に熱が伝わり、火傷をする恐れがあります。

★注意 ケガや本体破損、物品破損として拡大被害の原因となる行為を示します。

●水分、摩擦、日焼けなどにより、色落ちや色移り、型くずれが生じることがあります。●雨や水で濡れた場合は、すみやかに乾いた柔らかい布で水気を取り、 形を整えてください。●直射日光を避け、風通しのよい場所で乾燥させてください。高温(ドライヤーやストーブ等)での乾燥は行わないでください。●シンナー やベンジン等の薬品を使用すると、変色や型くずれの原因となります。●アウターグローブとインナーグローブは単体での使用はお止めください。●アウターグ ローブは洗濯できません。汚れた場合は市販のクリーナーをご使用ください。

メンテナンスについて

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を 中止しお買い求めいただいた販売店様、または弊社ユーザーサービス係に点検または修理を依頼してください。●アウターグローブは洗濯できません。汚れた場 合は市販のクリーナーをご使用ください。●インナーグローブのみ洗濯可能です。洗濯の際は色移りの可能性がありますので、他のものとは別に洗ってください。 ●洗濯後は形を整えてから陰干ししてください。また、乾燥機の使用は避けてください。●高温多湿を避け、風通しのよい場所に保管してください。●寒いところ に保管した際、革の油が凝固しカビのように見えることがあります。品質上問題はありませんが、気になる場合はブラシ等で除去してください。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載され た連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきま す。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。 1.素材の経年 劣化による損害など商品の寿命 / 2.改造および粗雑な取扱いによる故障 / 3.取扱説明書で禁止されている取扱いによる故障 / 4.不測の事故による商品 の故障 / 5.その他製造上の欠陥以外による製品の故障 / 6.ゴミやさびによる故障 / 7.分解したことによる不具合の発生または破損 / 8.落下やその他の衝 撃による部品の変形や破損による不具合 / 9.摩擦によるパーツの変化及びそれによる故障 / 10.他社製品との組み合わせによる故障

修理について

- ●本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。
- ●修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。
- ●修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。
- ●修理品の運賃並びに修理費については以下のように規定させていただきます。
 - 1.保証対象の場合:往復運賃並びに修理費は弊社にて負担いたします。
 - 2.保証対象以外の場合:往復運賃並びに修理費は、お客様のご負担とさせていただきます。

不明な点やお気付きの点がございましたら、 お問い合わせください。

スノーピークユーザーサービス 販売店様または弊社ユーザーサービスまで 0120-010-660 (9:00~17:00) Email:userservice@snowpeak.co.jp 株式会社スノーピーク

〒955-0147 新潟県三条市中野原456 Tel. 0256-46-5858 / Fax. 0256-46-5860 www.snowneak.co.in




Instruction Manual: Ver 4.00

UG-023BR Fireside Gloves

Thank you for purchasing a Snow Peak product. This product is a heat-resistant glove designed to be used by the bonfire or when cooking with Dutch ovens, etc. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

MARNING: This product contains chemicals known to the State of California to cause Cancer and Birth Defects or other Reproductive Harm. For more information go to www.P65warnings.ca.gov

Name of Parts



Specifications

- •Material: Outer Glove/ Cowhide, Inner Glove/ Flame-Retardant Cotton, Polyester
- •Size: One Size Fits All (Total Length 340mm / 13.4")
- •weight: 470g / 1.0 lbs

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

MARNING: Misuse could result in serious injury or death.

- •Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.
- •This product is not fire-resistant. Do not touch flames, burning firewood or charcoal directly.
- •Do not touch hot objects for long periods of time. Failure to do so may result in burns.

⚠ CAUTION: Misuse could result in injury to the user and/or damage to property.

- •Moisture, rubbing, sun exposure, etc. may cause discoloration, color transfer, or a loss of shape.
- •If the gloves get wet, dry them immediately with a soft, dry cloth, then reshape.
- Avoid direct sunlight and dry in a well-ventilated place.
- •The use of chemicals such as thinner and benzine may cause discoloration or loss of shape.
- •Do not use the outer gloves and inner gloves separately.

Maintenance

•Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair. •The outer glove is not washable. If the gloves get dirty, please use a cleaner on the market that matches the material. •Only the inner glove is washable. Wash separately because color transfer may occur onto other fabrics. •After washing, reshape the gloves before drying. Also, avoid using a dryer. •Please store this product in a well-ventilated area away from high temperatures and humidity. •When stored in a cold place, the oil on the leather may solidify and look like mold. This does not impact quality, but if you are concerned, you can remove it with a brush.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following: 1.Material deterioration caused by age. / 2.Damage caused by undifications or rough handling. / 3.Damage caused by inappropriate use not mentioned in the instruction manual. / 4.Damage caused by unexpected accidents. / 5. Any damage other than defects in the manufacturing process. / 6.Damage caused by dust or rust. / 7.Damage and defects caused by dismantling the product. / 8.Damage and defects caused by dropping, jolting or other shocks. / 9. Deterioration or failure of parts due to friction. / 10. Damage caused by the use of the product in combination with another manufacturer's products.

Repair

- •If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service. •When you request repairs, please make sure that the product is dry and clean. •Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred. •Transportation and repair costs are determined as follows.
- 1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak.
- 2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.

Snow Peak USA. Inc.

404 NW 23rd Avenue, Portland, Oregon 97210, USA Tel. +1 (503) 461-0781 / Instagram. @snowpeakusa Email. info@snowpeak.com / www.snowpeak.com

Snow Peak, Inc.

456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan Tel. +81 256-46-5858 / Fax. +81 256-46-5860 www.snowpeak.co.ip